iDECT

USER GUIDE

Freedom Twin
Freedom Triple
Freedom Quad

Digital Cordless Telephone with Answer Machine and Headset

Binatone Helpline (for UK only)
Monday to Friday from 9:00am to 5:00pm
Tel: 0845 345 9677
**Please note that all calls are charged at local rate
Or visit our website: **www.binatonetelecom.com**

THIS EQUIPMENT IS NOT DESIGNED FOR MAKING EMERGENCY TELEPHONE CALLS WHEN THE POWER FAILS. ALTERNATIVE ARRANGEMENTS SHOULD BE MADE FOR ACCESS TO DIAL EMERGENCY SERVICES.

Before operating this set,
please read these instructions carefully.

TECHNICAL DETAILS

Standard	Digital Enhanced Cordless Telecommunication (DECT)
Frequency range	1.88 to 1.9GHz (bandwidth =20 MHz)
Channel bandwidth	1.728 MHz
Operating range	Up to 300m outdoors; Up to 50m indoors For headset: Up to 150m outdoors; Up to 25m indoors
Operating time	Standby: 100 hours,Talking: 10 hours Battery charge time:15 hours For headset: Standby: 50 hours,Talking: 6 hours Battery charge time:15 hours
Temperature range	Operating 0˚C to 40˚C, Storage -20˚C to 60˚C
Electrical power	Base unit: Sunstrong: SSA-10W2 UK 058100/058060H input 200-240V~50Hz 0.3A, output 1: 5.8V ⎓ 600mA, output 2: 5.8V ⎓ 1000mA Charger unit: Ten Pao: S004LB0600030 / S004LV0600030 input 100-240VAC 50/60Hz 150mA, output 6VDC 300mA Handset Battery Information GPI - VT40AAAHC 2 x1.2V AAA size 400mAh NiMH BYD - H-AAA400A 2 x1.2V AAA size 400mAh NiMH CORUN - Ni-MH AAAJ400 2 x 1.2 AAA Size 400mAh NiMH

Caution

Risk of explosion if battery is replaced by an incorrect type

Dispose of used batteries according to the instructions.

Port specification

The port (connec ted to the mains power supply) is a SELV port with respect to EN41003.

The ☎ port (connected to the telephone line) is a TNV port with respect to EN41003.

CLEANING AND CARE

Do not clean any part of your phone system with benzene, thinners or other solvent chemicals as this may cause permanent damage which is not covered by the Guarantee.

When necessary, clean it with a damp cloth.

Keep your phone system away from **hot, humid conditions** or **strong sunlight,** and **don't let it get wet.**

Every effort has been made to ensure high standards of reliability for your phone system. However, if something does go wrong, please **do not try to repair it yourself, but** consult your supplier or the Helpline.

TABLE OF CONTENTS

1 IMPORTANT SAFETY INSTRUCTIONS 3

2 INSTALLING YOUR PHONE 5

2.1 CONNECTING THE BASE STATION 5
2.2 INSTALLING AND CHARGING THE BATTERIES 5
2.3 INSTALLING AND CHARGING THE WIRELESS HEADSET 5

3 GETTING TO KNOW YOUR PHONE 6

3.1 HANDSET OVERVIEW 6
3.2 DISPLAY ICONS AND SYMBOLS 7
3.3 BASE STATION WITH TELEPHONE ANSWERING MACHINE(TAM)CONTROL 8
3.4 BASE TWO DIGIT-LED DISPLAY INFORMATION 9
3.5 OVERVIEW OF THE WIRELESS HEADSET 9
3.6 WIRELESS HEADSET LED INDICATORS 10
3.7 MENU STRUCTURE 10
3.8 TEXT AND DIGIT ENTRY TABLE 11

4 USING YOUR PHONE 12

4.1 MAKE A CALL 12
4.2 ANSWER A CALL 12
4.3 END A CALL 12
4.4 HANDSET SPEAKERPHONE 13
4.5 ADJUST VOLUME 13
4.6 MUTE A CALL 13
4.7 TURN OFF HANDSET RINGER 13
4.8 TURN ON THE KEYPAD LOCK 13
4.9 REDIAL THE LAST NUMBER 13
4.10 FIND THE HANDSET 14
4.11 MAKE AN INTERNAL CALL(MULTI-HANDSET VERSIONS ONLY) 14

5 PRIVATE PHONEBOOK 16

5.1 ADD A NEW PHONEBOOK ENTRY 16
5.2 SEARCH FOR A PHONEBOOK ENTRY 16
5.3 VIEW A PHONEBOOK ENTRY 16
5.4 EDIT A PHONEBOOK ENTRY 17
5.5 DELETE A PHONEBOOK ENTRY 17
5.6 DELETE ALL PHONEBOOK ENTRIES 17
5.7 CHECK THE PHONEBOOK USAGE 17

6 CALLER DISPLAY (NETWORK DEPENDENT) 18
6.1 VIEW THE CALL LIST 18
6.2 STORE A CALL LIST NUMBER INTO THE PHONEBOOK 18
6.3 DELETE AN ENTRY IN THE CALL LIST 19
6.4 DELETE ALL CALL LIST ENTRIES 19
7 PHONE SETTINGS 20
7.1 DATE AND TIME SETTINGS 20
7.2 ALARM SETTINGS 21
7.3 HANDSET SETTINGS 22
7.4 BASE SETTINGS 24
7.5 REGISTRATION 25
7.6 RESET YOUR PHONE 26
8 ANSWERING MACHINE 27
8.1 TURN ON/OFF THE ANSWERING MACHINE 27
8.2 LISTEN TO THE MESSAGES IN THE ANSWERING MACHINE 27
8.3 DELETE ALL MESSAGES IN THE ANSWERING MACHINE 28
8.4 RECORD MEMO 28
8.5 ANSWERING MACHINE SETTINGS 29
REMOTE OPERATION 33
9 TROUBLESHOOTING 35
10 DECLARATION OF CONFORMITY 37
11 PRODUCT GUARANTEE 38

1 IMPORTANT SAFETY INSTRUCTIONS

When using your telephone equipment, basic safety precautions should always be followed to reduce the risk of fire, electric shock and injury, including the following:

1) Read and understand all the instructions.
2) Follow all warnings and instructions marked on the product.
3) Unplug this product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning.
4) Keep your phone away from hot, humid conditions or strong sunlight, and don't let it get wet or use this product near water (for example, near a bath tub , kitchen sink, swimming pool).
5) Do not overload wall outlets and extension cords as this can result in the risk of fire or electric shock.
6) Unplug this product from the wall outlet and refer servicing to our Repair Centre under the following conditions:
   - When the power supply cord or plug is damaged or frayed.
   - If the product does not operate normally by following the operating instructions.
   - If the product has been dropped and the cabinet has been damaged.
   - If the product exhibits a distinct change in performance.
7) NEVER use your phone outdoors during a thunderstorm-unplug the base from the telephone line and the mains socket when there are storms in your area. Damage caused by lightning is not covered by the guarantee.
8) Do not use the telephone to report a gas leak in the vicinity of the leak.
9) Use only the supplied NiMH (Nickel Metal Hydride) batteries! The operation periods for the handsets are only applicable with the default battery capacities
10) The use of other battery types or non-rechargeable batteries/primary cells can be dangerous. These may cause interference and/or damage to the unit or surroundings. The manufacturer will not be held liable for damage arising from such non-compliance.
11) Do not use third party charging bays. Damage may be caused to the batteries.
12) Please ensure the batteries are inserted in the correct polarity.
13) Dispose of batteries safely. Do not immerse them in water, burn them, or put them where they could get punctured.

Package contents

The Twin package contains the following items:

- 1 Handset
- 1 Base station
- 1 Headset unit
- 1 Mains power adapter
- 1 Telephone line cord
- 2 Rechargeable batteries
- 1 User manual

Note: If you have a Triple or Quad system, you will also have the requisite extra handset(s) and battery packs, and a charger pod for each extra handset.

Connection and conditions for use:

You can connect your phone to a direct exchange line (DEL) on a local exchange with its own phone number; to an extension socket connected to a DEL; or to an extension on an approved compatible PBX. Do not connect as an extension to a payphone.

The ringer equivalence numbers (REN) of all equipment (phones, fax machines, modems, etc.) connected to an exchange line must not add up to more than 4, otherwise one or more of them may not ring and/or answer calls correctly. The phone has a REN of 1, and most other telephones have a REN of 1 unless marked otherwise.

To use your handset and base together, you must be able to establish a radio link between them. The signal between the handset and the base is in accordance with the normal standards for a DECT phone: Maximum range up to 300 metres outdoors or 50 metres indoors, or 150 metres / 25 metres for the headset.

The signal range may decrease if there is any large metal object between the handset and the base, such as a refrigerator, a mirror, a filing cabinet, metallic doors or reinforced concrete. The signal strength may also be reduced by other solid structures like walls, or by other radio or electrical interference.

Headset operation - Calls cannot be made from the wireless headset, but incoming calls can be answered by the headset. If you want to make a call and use the headset, you will have to dial the number using a handset and then transfer the call to the headset, see section 4.11.3

2 INSTALLING YOUR PHONE

2.1 Connecting the base station



1. Plug the power supply and the telephone line cord into the base.
2. Plug the other end of the power adapter into a suitable 230Vac mains socket, and the line cord into your telephone line socket.
3. Use only the power adapter and telephone line cord supplied.

2.2 Installing and charging the batteries



1. Place the 2 supplied batteries into the battery compartment with the polarity markings as shown Use only the NiMH rechargeable battery type provided.
2. Position the battery compartment cover over the batteries and slide up to click into place.
3. Put the handset on the base and charge for 15 hours before using the handset for the first time. The handset will give a beep when it is properly placed on the base or charger.

2.3 Installing and charging the wireless headset



1. Attach the ear hook to the headset body as indicated, for either left or right ear operation, according to your preference.
2. Put the wireless headset on the base cradle for charging before using. The LED on the headset will light red when it is first placed on the charger, and will light blue when it is fully charged.

Note: The headset battery is not a user-accessible or replaceable part.

If you have a Broadband line

If you connect your telephone to a line with a broadband connection, you will need to insert a micro-filter between the telephone and the telephone line, otherwise you may get interference between the telephone and the broadband, which could cause problems.



In a home with broadband, every telephone must have a micro-filter connected, not just the one at the telephone point that your modem is connected to.
If you need more broadband micro-filters, contact your broadband supplier.

3 GETTING TO KNOW YOUR PHONE

3.1 Handset Overview

LEFT SOFT KEY Menu / OK
In idle mode:Press to access the main menu
In sub-menu mode:
Press to confirm the selection
During a call: Press to access Intercom/Phonebook/ Redial List/ Call List

TALK Talk
In idle / predialling mode:
Press to make a call
In Redial list / Call List / Phonebook list:
Press to make a call to the displayed entry.
During ringing:
Press to answer a call

DOWN Redia ▼
In idle mode:
Press to access the redial list
In menu mode:
Press to scroll down the menu items
In Phonebook list / Redial list / Call List:
Press to scroll down the list
During a call:
Press to decrease the earpiece volume
During ringing:
Press to decrease the ringer volume

SPEAKERPHONE
During a call:
Press to turn on / off the speakerphone.
In Redial List / Call List / Phonebook List:
Press to make a call with speakerphone
During ringing:
Press to answer a call with speakerphone



UP ▲ Calls
In idle mode:
Press to access the call list
In menu mode:
Press to scroll up the menu items
In Phonebook list / Redial list / Call List:
Press to scroll up the list
During a call:
Press to increase the earpiece volume
During ringing:
Press to increase the ringer volume

RIGHT SOFT KEY C/ Mute
(CLEAR/BACK/MUTE/ INTERCOM)
In main menu mode: Press to go back to idle screen
In sub-menu mode: Press to go back to previous level
In sub-menu mode: Press and hold to go back to idle screen
In editing / predialling mode:
Press to clear a character / digit
In editing / predialling mode:
Press and hold to delete all the characters / digits
During a call: Press to mute/ unmute the microphone
In idle mode:Press to intercom another handset

OFF Off
During a call: Press to end a call and go back to idle screen
In menu / editing mode: Press to go back to previous menu
In idle mode:
Press and hold to power off the handset
In idle mode (when the handset is powered off): Press and hold to power on the handset.

Flash
RECALL(also called FLASH)
In idle / predialling mode:
Press to insert a recall
During a call:Press to dial a recall

3.2 Display Icons and Symbols

The LCD display gives you information on the current status of the telephone.



Steady when the handset is in range of the base. Flashes when out of range of the base or not registered to the base.

Steady when an intercom call is in progress.
Flashes when there is an incoming internal call.

Indicates a call is in progress on that handset.

Indicates that Speakerphone is being used.

Indicates that your answering machine (TAM) is on and flashes when there is a new message.

Indicates that the handset ringer is switched off.

Steady when an alarm is set. Flashes when the alarm is sounding.

Indicates that the keypad is locked.

Indicates when you have a new Voice Mail message.
(This is a Caller Display service and is not usually available from UK network providers.)

Indicates when the battery is fully charged.
Whole icon flashes when the battery is charging.
Internal block icon flashes when the battery is in final charging stage.

Indicates when the battery needs charging.
Flashes when low battery power level is detected.

Indicates when there are more characters or numbers in front of those being displayed.

Indicates when there are more characters or numbers after those being displayed.

LEFT SOFT KEY function. Press to access the main menu.

OK LEFT SOFT KEY function. Press to confirm the current selection.

Indicates new TAM message / new call in TAM message list / call list.

Indicates more options available in lists, above or below.

(INT) RIGHT SOFT KEY function. Press to start an intercom call.

(BACK) RIGHT SOFT KEY function. Press to go back to the previous menu level or cancel the current action.

C RIGHT SOFT KEY function. Press the alarm, or mute/unmute the microphone during a call.

3.3 Base Station with Telephone Answering Machine (TAM) Control



1 FIND

a) Press to find/page all registered handsets or the wireless headset. Press the button again, or TALK/OFF/RIGHT SOFT KEY on the handset, to turn off page signal.

b) Press and hold to put the base unit into registration mode, when registering a new handset or headset.

2 ANSWER ON/OFF

a) Press to turn on/off the answering machine.

3 DELETE (DEL)

a) In idle mode: Press and hold to delete all messages, if all of the messages in the answering machine have been reviewed.

b) During message playback: Press to delete the current message.

4 VOLUME (▼–)

a) In idle mode, during message playback or during call screening: Decrease the loudspeaker volume by one level (0 to 8).

5 VOLUME (▲+)

a) In idle mode, during message playback or during call screening: Increase the loudspeaker volume by one level (0 to 8).

6 REPEAT (REPEAT ◀◀)

a) During message playback: Press once to repeat the current message from the beginning. Press twice to playback the previous message.

7 PLAY/STOP (PLAY/STOP ▶/■)

a) In message playback mode: Press to playback or stop playing messages.

8 SKIP (SKIP ▶▶)

a) In message playback mode: Press to play the next message.

3.4 Base Two Digit-LED Display Information

- `- -` Steadily ON: Answering machine is OFF.
- `00` Steadily ON: There are no voice messages in the answering machine.
- `09` Flash in idle mode: Indicates the number of new answering machine messages. (e.g. there are 9 answering machine messages in total, with a capacity for 59.
  Flashing during message playing: The selected new answering machine message is being played.
  Steadily ON: All the new messages have been read and there are 9 answering machine messages in total.
- `FF` Flashing: TAM memory is full.
- `- -` Flashing: Time is not set and only old messages remain.
- `An/09` Flashing: Indicates an incoming call / recording of an incoming call. The number (e.g. 09) indicates the total number of new messages.
- *rA* Flashing: Indicates the line remote access is in progress.
- `L3` Steadily ON: Indicates the base speaker volume level is 3. Nine volume levels from L0 to L8 are provided (L0 means ringer off). `L3` disappears after 3 seconds.

3.5 Overview of the Wireless Headset

1 POWER/TALK ON/OFF

a) In idle mode: Press and hold to power the wireless headset on or off.
b) During ringing: Press to answer the call.
c) During a call: Press to end the call.
d) During registration: Press to exit the registration mode.

2 VOLUME UP/FLASH (+)

a) During a call: Press to increase the earpiece volume.
b) During ringing: Press to increase the ringer volume.

3 VOLUME DOWN (–)

a) During a call: Press to decrease the earpiece volume.
b) During ringing: Press to decrease the ringer volume.

NOTE: If the wireless headset is not registered, press and hold **VOLUME UP/ FLASH** together with **VOLUME DOWN** to initiate the registration mode.

3.6 Wireless Headset LED Indicators

Purple:

Steadily on: The wireless headset is unregistered.

Flashing: The wireless headset is registered but the base is not available (searching or out of range).

Blue:

Steadily on: When the headset is seated in the base and fully charged. Once the headset is successfully registered, the blue light will flash on then off, for about three seconds at a time, and emit a long beep.

Single flashing: The wireless headset is in idle mode and off the base.

Double flashing: The wireless headset is on a call, and if the signal becomes weak, double beeps will be heard.

Continuously flashing: The wireless headset is ringing. A ringing will also be heard in the earpiece.

Red:

Steadily on: When the wireless headset is charging on the base.

Single flashing: Indicates that the battery is low, the unit is not on the base, and the headset will emit short double beeps.

Double flashing: Indicates that the battery is low while the headset is in use and short double beeps will be emitted.

Triple flashing: Indicates powering on/off the headset and three short beeps will be emitted through the earpiece.

Red/Blue:

Toggling display: The wireless headset is in registration mode. When the headset is registered successfully, the headset will beep for around 3 seconds.

3.7 Menu Structure

In idle mode, press <MENU/OK> to go to CALL LIST, the first option in the menu list.

Press <UP> or <DOWN> to go to other options in the menu list.

Press <MENU/ OK> to enter a sub-menu or function.

Press <C/MUTE> to go back to the previous level.

Refer to the following for the menu structure.



Main Menu	CALL LIST	PHONEBOOK	BS SETTINGS	HS SETTINGS	REGISTRATION	DEFAULT	ANS. MACHINE
Sub menu	Shows EMPTY or the first Call List Entry. Then <MENU/OK> for: ADD TO PB DELETE DELETE ALL DETAILS	Shows EMPTY or the first phonebook Entry. Then <MENU/OK> for: ADD PB STATUS or ADD VIEW EDIT DELETE DELETE ALL PB STATUS	BS RINGER RING VOLUME DELETE HS FLASH TIME CHANGE PIN	ALARM RING SETUP TONE SETUP LANGUAGE RENAME HS HS DISPLAY AUTO ANSWER DATE & TIME	PIN?----	PIN?----	MSG PLAYBACK DELETE ALL MEMO TAM ON/OFF TAM SETTINGS ANSWER MODE OGM SETTINGS ANSWER DELAY RECORD TIME REMOTE ACC COMPRESSION BS SCREENING CHANGE PIN

3.8 Text and Digit Entry Table

The following table shows you where each letter and punctuation character can be found, by using repeated presses of the alphanumeric keypad. This will be helpful when storing a name in the phonebook and renaming your handset.
In editing mode, a cursor is displayed to indicate the current text entry position. It is positioned at the right of the last character entered.

Writing Tips:

1. Once a character is selected, the cursor will move to the next position after a short pause.
2. You can move the cursor within the text with the <UP/DOWN> keys to amend the text entry.
3. Press <C/MUTE> to delete the last character.
4. Press and hold <C/MUTE> to delete the entire text string.

3.8.1 English Character Set

	Alphanumeric Editing (For phonebook name editing and renaming handset)										Number Editing (For phone number editing,date/time editing)
Key Press	1st	2nd	3rd	4th	5th	6th	7th	8th	9th	10th	
1	space	-	1								1
2	A	B	C	2							2
3	D	E	F	3							3
4	G	H	I	4							4
5	J	K	L	5							5
6	M	N	O	6							6
7	P	Q	R	S	7						7
8	T	U	V	8							8
9	W	X	Y	Z	9						9
0	0										0, or P (Pause) if press and hold
*	*	?	/	\	(	)					*
#	o	'	,	-	&						#

Some other characters are available with some of the alternative handset language options (see 7.3.5).

4 USING YOUR PHONE

4.1 Make a Call

4.1.1 Preparatory Dialling

Enter the phone number and press <TALK> to connect to the line and dial the number. When entering the number, if you make a mistake, press <C/MUTE> to delete digits.

4.1.2 Direct Dialling

Press <TALK> to connect to the line and then enter the phone number.
(Note: if you enter a wrong digit you cannot correct it with the <C/MUTE> key.)

4.1.3 Call from the phonebook

Press <MENU/OK>, <DOWN>, <MENU/OK> to access the phonebook and press <UP/DOWN> to select the desired phonebook entry.
Press <TALK> to dial out the selected phonebook entry.
Note: The alphanumeric keys provide a short-cut to find entries beginning with the corresponding letters.

4.1.4 Call from the Call List (only available with Caller Display)

Press <UP/CALLS> to access the Call List and press <UP/DOWN> to select the desired Call List entry.
Press <TALK> to dial out the selected Call List entry.
Note: You can also access the Call List by pressing <MENU/OK> twice.

4.1.5 Call from the redial list

Press <DOWN/REDIAL> to access the redial list and press <UP/DOWN> to select the desired redial number.
Press <TALK> to dial out the selected redial number.

4.1.6 Call timer

Your handset automatically times the duration of every call.
The call timer is displayed as soon as you answer a call or 15 seconds after dialling and remains on the screen for 5 seconds after the end of the call.
It is shown in hours, minutes and seconds format (HH:MM:SS).

4.2 Answer a Call

If the handset is not on the charging cradle:

When the phone rings, press <TALK> to answer a call.

Note: If AUTO ANSWER is set to ON, then lifting the handset off the base or charger will answer the call automatically, and no buttons need to be pressed.

4.3 End a Call

During a call press <OFF> to end the call.
OR
Put the handset on the base station or charger to end the call.

4.4. Handset Speakerphone

During a call, you can press **SPEAKERPHONE** to alternate between hands-free speakerphone and normal handset use.

4.5 Adjust Volume

There are 5 levels (VOLUME 1 to VOLUME 5) to choose from for each of the earpiece and speaker volumes.

During a call:

Press <UP/DOWN> to select volume 1-5. The current setting is shown.
When you end the call, the setting will remain at the last selected level.

4.6 Mute a Call

You can talk to someone nearby without letting the caller hear you during a call.
During a call:
Press <C/MUTE> to mute the microphone and "***MUTED***" will display on the LCD.
Your caller cannot hear you. Press <C/MUTE> again to unmute the microphone.

4.7 Turn off the Handset Ringer

In idle, press and hold <HASH/#> to turn off the handset ringer. The "RINGER OFF" icon is displayed on the LCD.

Note: The display will still flash the Call icon and show CALL or the Caller Display number, when there is an incoming call, even if the ringer is turned off. To turn the ringer back on, press and hold <HASH/#> again.

4.8 Turn on the Keypad Lock

You can lock the keypad so that it cannot be used accidentally while carrying it around. In idle, press and hold <STAR/*> to turn on the keypad lock, and the <KEY LOCK> icon will display.

Note: You can still use <TALK> to answer a call when the handset is ringing. To turn the keypad lock off, press and hold <STAR/*> again.

4.9 Redial the last number

You can redial any of the 10 last numbers called. If you have stored a name in phonebook to go with the number, the name will be displayed instead.
The most recent last number will display at the top of the redial list.

4.9.1 Redial a Number from the Redial List

1. In idle mode, press <DOWN/REDIAL> to access the redial list.

Note: If the redial list entry shows a name, press <Hash/#> to view the number of this entry.

2. Press <UP/DOWN> to browse the redial list.
3. Press <TALK> to dial to the selected redial number.

Note: If there are no numbers in the redial list, the display shows ***"EMPTY"***.

4.9.2 Store a Redial Number into the Phonebook

1. Follow Steps 1 and 2 in section 4.9.1.
2. Press <MENU/OK> and <UP/DOWN> to select **ADD TO PB.**
3. Press <MENU/OK> and then enter the name you want to use in the phonebook.
4. Press <MENU/OK> and then modify the number, if necessary.
5. Press <MENU/OK> to show <MELODY 1>.
6. Press <UP/DOWN> to browse the ringtone list. The respective ringtone will be played when browsing the ringtone list. (Note: the selected melody will only be played when you receive a call if you subscribe to Caller Display and the incoming number matches the stored number.)
7. Press <MENU/OK> to confirm, and the entry will be stored.

4.9.3 Delete a Redial Number

1. Follow Steps 1 and 2 in section 4.9.1.
2. Press <MENU/OK> and <UP/DOWN> to select **DELETE.**
3. Press <MENU/OK> to confirm, and the entry will be deleted.

4.9.4 Delete all Redial List entries

1. Follow Steps 1 and 2 in section 4.9.1.
2. Press <MENU/OK> and <UP/DOWN> to select **DELETE ALL.**
3. Press <MENU/OK> to display <CONFIRM?>.
4. Press <MENU/OK> to confirm. All entries will be deleted and the display will show <EMPTY>.

4.10 Find the Handset

You can locate the handset by pressing the Find button FIND in the middle of the front of the base station. All the handsets registered to the base will produce the paging tone and show "PAGING" on the display for 60 seconds. You can stop the paging by pressing <TALK>/ <OFF> /<C> on any handset or <FIND> on the base again.

Note: If there is an incoming call during paging, the phone will ring with the incoming call instead of paging.

4.11 Make an Internal Call (Multi - handset versions only)

This feature is only applicable when there are at least two registered handsets or at least one handset and a headset.

It allows you to make internal calls, transfer external calls from one handset to another handset / headset and make conference calls. If the called handset / headset is not answered within 60 seconds, the called handset / headset will stop ringing and the calling handset will return to standby mode.

Note: If only one handset is registered to the base station, when <C/MUTE> is pressed, it will display ***"NOT POSSIBLE".***

4.11.1 Intercom Another Handset or Headset

1. In idle mode, press <C/MUTE> and all the other registered handset / headset numbers will display, along with a "9".
2. Enter the number of the handset / headset that you want to call, or enter "9" to call all handsets and headsets.
3. The called handset / headset rings and <TALK> must be pressed on that handset / headset to establish the intercom call.

Note: If only one other handset / headset is registered to the base station, pressing <C/MUTE> will call the other handset / headset immediately.

Note: If there is an external call while you are on an intercom call, you'll hear warning beeps, and you have to end the intercom call, before you can answer the external call.

4.11.2 Call All Handsets and Headsets

1. In idle mode, press <C/MUTE> and the registered handset / headset numbers will display.
2. Press the < 9 > key to ring to all registered handsets / headsets.

4.11.3 Transfer an External Call to another handset / headset

During an external call:

1. Press <MENU/OK> and <UP/DOWN> to select **INTERCOM.**
2. Press <MENU/OK> to show all the other registered handset / headset numbers, plus "9". Enter the number for the handset / headset you want to transfer the call to.
3. The external call is put on hold automatically and the called handset / headset rings.
4. Press <TALK> on the called handset / headset to establish an internal call.
5. Press <OFF> on the calling handset or put the calling handset on the charging cradle to end the current call with the external party.
6. The external call is transferred to the called handset / headset.

Note: If the other handset / headset has not answered the intercom call, you can stop the intercom and return to the external call by pressing <OFF>.

4.11.4 Make a 3-way Conference Call

The conference call feature allows one external call to be shared with two handsets or one handset and a headset (in intercom).

The three parties can share the conversation and no additional network subscription is required.

During an external call:

1. Follow Steps 1 to 4 in section 4.11.3.
2. Press and hold the star key <*> on the calling handset to establish the conference call.

   Either handset / headset can exit the conference by pressing <OFF>, leaving the other handset / headset still connected to the external call.

5 PRIVATE PHONEBOOK

Each handset can store up to 50 private phonebook entries with names and numbers. Each phonebook entry can have a maximum of 20 digits for the phone number and 12 characters for the name. You can also select different ringtones for your phonebook entries. (Note: the different ringtones only play when you receive a call if you subscribe to Caller Display and the incoming number matches the stored number.) Phonebook entries are stored alphabetically by name.

5.1 Add a New Phonebook Entry

In idle:

1. Press <MENU/OK> and <UP/DOWN> to select **PHONEBOOK** and then press <MENU/OK> to access the phonebook.
2. Press <MENU/OK> to show **ADD.**
3. Press <MENU/OK> and then enter the name.
4. Press <MENU/OK> and then enter the number.
5. Press <MENU/OK> and <UP/DOWN> to select the desired ringtone for your phonebook entry.
6. Press <MENU/OK> to store the phonebook entry.

5.2 Search for a Phonebook Entry

In idle:

1. Press <MENU/OK> and <UP/DOWN> to select PHONEBOOK and then press <MENU/OK> to access the phonebook.
2. Enter the first letter of the name using the alphanumeric keys (e.g. if it begins with C, press the 2 key three times), and then <UP/DOWN> to scroll to the entry you want.

5.3 View a Phonebook Entry

In idle:

1. Press <MENU/OK> and <UP/DOWN> to select PHONEBOOK and then press <MENU/OK> to access the phonebook.
2. Press <UP/DOWN> to select the desired phonebook entry.
3. Press <MENU/OK> and <UP/DOWN> to select **VIEW.**
4. Press <MENU/OK> and <UP/DOWN> to review the name, number and ringtone of the selected phonebook entry.

Note: If the number is more than 12 digits, press <LEFT SOFT KEY> or <RIGHT SOFT KEY> to view the remaining digits.

5.4 Edit a Phonebook Entry

In idle:

1. Press <MENU/OK> and <UP/DOWN> to select PHONEBOOK and then press <MENU/OK> to access the phonebook.
2. Press <UP/DOWN> to select the desired phonebook entry.
3. Press <MENU/OK> and <UP/DOWN> to select **EDIT.**
4. Press <MENU/OK> to display the current name.
5. Edit the name and press <MENU/OK>.
6. Edit the number and press <MENU/OK>.
7. Press <UP/DOWN> to select the ringtone and press <MENU/OK> to confirm.

5.5 Delete a Phonebook Entry

In idle:

1. Press <MENU/OK> and <UP/DOWN> to select PHONEBOOK and then press <MENU/OK> to access the phonebook.
2. Press <UP/DOWN> to select the desired phonebook entry.
3. Press <MENU/OK> and <UP/DOWN> to select **DELETE.**
4. Press <MENU/OK> to confirm, and the entry will be deleted.

5.6 Delete all Phonebook entries

1. Press <MENU/OK> and <UP/DOWN> to select PHONEBOOK and then press <MENU/OK> to access the phonebook.
2. Press <MENU/OK> and <UP/DOWN> to select **DELETE ALL.**
3. Press <MENU/OK> to display <CONFIRM?>.
4. Press <MENU/OK> to confirm. All entries will be deleted and the display will show <EMPTY>.

5.7 Check the Phonebook Usage

You can check how many phonebook entries are stored in your handset and how many phonebook entries are available for you to store in the phonebook.

1. Press <MENU/OK> and <UP/DOWN> to select PHONEBOOK and then press <MENU/OK> to access the phonebook.
2. Press <MENU/OK> and <UP/DOWN> to select **PB STATUS.**
3. Press <MENU/OK> to display how much of the phonebook is being used, for example <14/50> means 14 entries are stored out of the total 50 available spaces.

6 CALLER DISPLAY (NETWORK DEPENDENT)

This feature is available if you have subscribed to the Calling Line Identification service with your network service provider. Your phone can store up to 20 received calls with date/time information in the Call List. The number will be shown on the handset display when the phone is ringing. If the number matches with one of the entries in your Private Phonebook, the caller's name stored in the private phonebook will be displayed alternately with the number, and the handset will ring with the ringtone associated with that phonebook entry.

If the call is from someone who withheld their number, e.g. by dialling 141, ***"WITHHELD"*** will display.

If the call is from someone whose number is unavailable, e.g. an international call or from a private exchange, ***"OUT OF AREA"*** will display.

If you've got new Caller Display records, the handset will display "X NEW CALLS" in standby mode. The New Calls indication will remain until all the new call records have been viewed on that handset.

6.1 View the Call List

All received calls are saved in the Call List with the latest call at the top of the list. When the call list is full, the oldest call will be replaced by a new call. Any unanswered calls which have not been viewed are marked with a <*> icon at the centre of the bottom line of the display.

1. Press <UP/CALLS> to access the call list.

OR Press <MENU/OK> and <UP/DOWN> to show CALL LIST, the press OK.

2. Press <UP/DOWN> to select the desired entry.
3. Press <#> to view the caller's number if applicable.
4. Press <MENU/OK>, <UP/DOWN> to show DETAILS, and then <MENU/OK> to display the date and time of the call. Press <MENU/OK> to go back to the previous screen.

6.2 Store a Call List Number into the Phonebook

1. Follow Steps 1 and 2 in Section 6.1.
2. Press <MENU/OK> and <UP/DOWN> to show **ADD TO PB.**
3. Press <MENU/OK> and then enter the name.
4. Press <MENU/OK> and the selected call list number is displayed.
5. Edit the number if necessary.
6. Press <MENU/OK> and <UP/DOWN> to select the ringtone.
7. Press <MENU/OK> to store the phonebook entry and return to the calls list.

6.3 Delete an entry in the Call List

1. Follow Steps 1 and 2 in Section 6.1.
2. Press <MENU/OK> and <UP/DOWN> to select **DELETE.**
3. Press <MENU/OK> to confirm.

6.4 Delete all Call list entries

1. Follow Steps 1 and 2 in Section 6.1.
2. Press <MENU/OK> and <UP/DOWN> to select **DELETE ALL.**
3. Press <MENU/OK> to display <CONFIRM?>.
4. Press <MENU/OK> to confirm. All entries will be deleted and the display will show<EMPTY>.

7 PHONE SETTINGS

Your phone comes with a selection of settings that you can change to personalise your phone the way you like it to work.

7.1 Date and Time Settings

If you subscribe to Caller Display the time and date settings will be automatically updated by the network when you receive an incoming call.

The Caller Display service only sends the month and date, not the year, so you may need to set the year.

7.1.1 Change the Date Format

1. Press <MENU/OK> and <UP/DOWN> to select **HS SETTINGS.**
2. Press <MENU/OK> and <UP/DOWN> to select **DATE & TIME.**
3. Press <MENU/OK> and <UP/DOWN> to select **DATE FORMAT.**
4. Press <MENU/OK> and <UP/DOWN> to select your desired date format **(DD-MM-YY**or **MM-DD-YY**).
5. Press <MENU/OK> to confirm.

7.1.2 Change the Time Format

1. Press <MENU/OK> and <UP/DOWN> to select **HS SETTINGS.**
2. Press <MENU/OK> and <UP/DOWN> to select **DATE & TIME.**
3. Press <MENU/OK> and <UP/DOWN> to select **TIME FORMAT.**
4. Press <MENU/OK> and <UP/DOWN> to select your desired time format (**12 HR** or **24 HR**).
5. Press <MENU/OK> to confirm.

7.1.3 Set the Time

1. Press <MENU/OK> and <UP/DOWN> to select **HS SETTINGS.**
2. Press <MENU/OK> and <UP/DOWN> to select **DATE & TIME.**
3. Press <MENU/OK> and <UP/DOWN> to select **SET TIME.**
4. Press <MENU/OK> and then enter the time information in 24 hour format.
5. Press <MENU/OK> to confirm.

Note: If time has been set before, the current time will display, otherwise, ***"HH:MM"*** will display.

7.1.4 Set the Date

1. Press <MENU/OK> and <UP/DOWN> to select **HS SETTINGS.**
2. Press <MENU/OK> and <UP/DOWN> to select **DATE & TIME.**
3. Press <MENU/OK> and <UP/DOWN> to select **SET DATE.**
4. Press <MENU/OK> and then enter the date information in the format you set in Section 7.1.1.
5. Press <MENU/OK> to confirm.

Note: If date has been set before, the current date will display, otherwise, "***DD-MM-YY*** " will display.

7.2 Alarm Settings

You can set an alarm time on this phone. When an alarm is set, the alarm icon <☎> is shown on the handset display. When the alarm time is reached, the alarm icon<☎> and "***ALARM ON*** " flash on the handset display, and the alarm tone rings for 45 seconds. You can press any key to disable the alarm. If the snooze function is activated, the alarm will sound again at the end of the snooze period of seven minutes. You can also press and hold <OFF> while the alarm is sounding, to stop the alarm and turn off the snooze function.

Note:

a. A key press will still disable the alarm even if the handset keypad is locked when the alarm rings.
b. The alarm volume level is the same as the settings of the handset ringer volume. If the handset ringer is set to **VOLUME OFF**, the alarm still sounds at **VOLUME 1** level.
c. During an external call or internal call, if an alarm is set and when the alarm time is reached, the <☎> and **"ALARM ON"** will still flash. An is reached. alarm tone will be emitted from the earpiece to alert the user the alarm time Once the user presses any key or presses and holds.
<OFF> to disable the alarm, the display will revert to the call duration.
d. During paging or ringing, the alarm will not sound when the alarm time is reached. However, if the snooze function is enabled and there is no paging or ringing, the alarm will sound again at the end of the snooze period.

7.2.1 Turn on/off the Alarm

1. Press <MENU/OK> and <UP/DOWN> to select **HS SETTINGS.**
2. Press <MENU/OK> and <UP/DOWN> to select **ALARM.**
3. Press <MENU/OK> and <UP/DOWN> to select **ON/OFF.**
4. Press <MENU/OK> to confirm.

Note: If ON is selected, you will be asked to set the alarm time.

7.2.2 Set the Alarm Time (If Alarm time is set to be ON)

1. Follow Steps 1 to 4 in Section 7.2.1.
2. Enter the alarm time in24 hour format.
3. Press <MENU/OK> to display "SNOOZE".
4. Press <MENU/OK> and <UP/DOWN> to select snooze **ON** or **OFF.**
5. Press <MENU/OK> to confirm.

7.3 Handset Settings

7.3.1 Set the Ringer Melody for Internal Calls

1. Press <MENU/OK> and <UP/DOWN> to select **HS SETTINGS.**
2. Press <MENU/OK> and <UP/DOWN> to select **RING SETUP.**
3. Press <MENU/OK> and <UP/DOWN> to select **INT RING.**
4. Press <MENU/OK> and <UP/DOWN> to select the melody you want to hear for internal calls.

Note: The respective melody will be played while browsing the ringtone list.

5. Press <MENU/OK> to confirm.

7.3.2 Set the Ringer Melody for External Calls

1. Press <MENU/OK> and <UP/DOWN> to select **HS SETTINGS.**
2. Press <MENU/OK> and <UP/DOWN> to select **RING SETUP.**
3. Press <MENU/OK> and <UP/DOWN> to select **EXT RING.**
4. Press <MENU/OK> and <UP/DOWN> to select melody you want to hear for external calls.

Note: The respective melody will be played while browsing the ringtone list.

5. Press <MENU/OK> to confirm.

7.3.3 Set the Ringer Volume

1. Press <MENU/OK> and <UP/DOWN> to select **HS SETTINGS.**
2. Press <MENU/OK> and <UP/DOWN> to select **RING SETUP.**
3. Press <MENU/OK> and <UP/DOWN> to select **RING VOLUME.**
4. Press <MENU/OK> and <UP/DOWN> to select the desired ringer volume (a total of 6 ringer volume levels including **VOLUME OFF**).

Note: The respective ringer volume will be played during your selection.
If **VOLUME OFF** is selected, the <Ringer Off> icon will be displayed.

5. Press <MENU/OK> to confirm.

7.3.4 Set Alert Tones

Three different alert tones are set on by default, but can be turned off, if desired.

Key Tone - a single beep is emitted when you press a key.

Low Battery Tone - emitted while you are talking on the phone to alert you that you need to charge the handset batteries.

Out of Range Tone - emitted while you are talking on the phone to alert you to move closer to the base unit, before the call is lost.

1. Press <MENU/OK> and <UP/DOWN> to select **HS SETTINGS.**
2. Press <MENU/OK> and <UP/DOWN> to select **TONE SETUP.**
3. Press <MENU/OK> and <UP/DOWN> to select **KEY TONE / BATTERY TONE/OUT OF RANGE.**
4. Press <MENU/OK> and <UP/DOWN> to turn on or off these tones.
5. Press <MENU/OK> to confirm.

7.3.5 Set the Handset Language

1. Press <MENU/OK> and <UP/DOWN> to select **HS SETTINGS.**
2. Press <MENU/OK> and <UP/DOWN> to select **LANGUAGE.**
3. Press <MENU/OK> and <UP/DOWN> to select the desired language.
4. Press <MENU/OK> to confirm.

7.3.6 Rename the Handset

1. Press <MENU/OK> and <UP/DOWN> to select **HS SETTINGS.**
2. Press <MENU/OK> and <UP/DOWN> to select **RENAME HS.**
3. Press <MENU/OK> and change the name of your handset, using <C/MUTE> to delete letters and the alphanumeric keys to enter up to 10 letters for the name.
4. Press <MENU/OK> to confirm.

7.3.7 Choose the Information to be Displayed in Idle

You can choose to display the time or handset name in your idle screen.

1. Press <MENU/OK> and <UP/DOWN> to select **HS SETTINGS.**
2. Press <MENU/OK> and <UP/DOWN> to select **HS DISPLAY.**
3. Press <MENU/OK> and <UP/DOWN> to select **HANDSET NAME** or **TIME.**
4. Press <MENU/OK> to confirm.

Note: If TIME is selected, but no time has been set the display still shows the time starting from 00--00 after power-up or a reset.

7.3.8 Set the Auto Answer

If you turn on the Auto Answer, you can answer a call automatically by just lifting the handset off the base or charger, without having to press any key.

1. Press <MENU/OK> and <UP/DOWN> to select **HS SETTINGS.**
2. Press <MENU/OK> and <UP/DOWN> to select **AUTO ANSWER.**
3. Press <MENU/OK> and <UP/DOWN> to turn on or off the auto answer feature.
4. Press <MENU/OK> to confirm.

7.4 Base Settings

7.4.1 Set the Base Ringer Melody

1. Press <MENU> and <UP/DOWN> to select **BS SETTINGS.**
2. Press <OK> and <UP/DOWN> to select **BS RINGER.**
3. Press <OK> and <UP/DOWN> to select the desired melody you want from a choice of 5.

Note: The respective ringer melody will be played while browsing the melody list.

4. Press <OK> to confirm.

7.4.2 Set the Ringer Volume

1. Press <MENU> and <UP/DOWN> to select **BS SETTINGS.**
2. Press <OK> and <UP/DOWN> to select **RING VOLUME.**
3. Press <OK> and <UP/DOWN> to select the desired ringer volume (a total of 6 ringer volume levels including **VOLUME OFF**).

Note: The respective ringer volume will be played during your selection.

4. Press <OK> to confirm.

7.4.3 De-register a Handset

This operation should only be necessary if one of your handsets becomes faulty or lost and needs to be replaced.

You will need to enter the 4-digit system PIN (Default PIN is 0000) in order to de-register a handset from the base station. A de-registered handset will have the antenna flashing and REGISTER on the display.

Note: You cannot de-register the handset that you are currently using.

1. Press <MENU/OK> and <UP/DOWN> to select **BS SETTINGS.**
2. Press <MENU/OK> and <UP/DOWN> to select **DELETE HS.**
3. Press <MENU/OK> and the display shows PIN?----
4. Enter the 4-digit system PIN.
5. Press <MENU/OK> and the first handset number is displayed.
6. Press <UP/DOWN> to step through the list of registered handsets, and select the number of the handset you want to de-register.
7. Press <MENU/OK> to confirm, and the chosen handset will be de-registered.

7.4.4 Change the Flash (Recall) Time

You may need to change the recall (flash) time if your phone is connected to a PBX. The recall time options are SHORT (the default value of 100ms), MEDIUM (300ms) or LONG (600ms).

1. Press <MENU/OK> and <UP/DOWN> to select **BS SETTINGS.**
2. Press <MENU/OK> and <UP/DOWN> to select **FLASH TIME.**
3. Press <MENU/OK> and <UP/DOWN> to select your desired flash time **(SHORT,MEDIUM, LONG,** with the current setting indicated by an asterisk.
4. Press <MENU/OK> to confirm.

7.4.5 Change the System PIN Code

A 4-digit system PIN code is used for changing the system settings of the base station. It is used to protect your phone against unauthorised use. The default system PIN code is 0000.

1. Press <MENU/OK> and <UP/DOWN> to select **BS SETTINGS.**
2. Press <MENU/OK> and <UP/DOWN> to select **CHANGE PIN.**
3. Press <MENU/OK> and the display shows PIN?------
4. Enter the old system PIN.
5. Press <MENU/OK> to display NEW PIN?------, and enter your new 4-digit system PIN.
6. Press <MENU/OK> to display CONFIRM?------, and enter your new 4-digit system PIN again.

Note: If the new PIN entered in Step 6 is not the same as the new system PIN entered in Step 5 you must enter the new system PIN at step 5 again.

7. Press <MENU/OK> to confirm

7.4.6 PBX ACCESS

If you use the phone on a PBX that needs an access digit to get an external line, a single digit can be set to dial automatically before any Phonebook or Calls List number.

1. Press <MENU/OK> and <UP/DOWN> to select **BS SETTINGS.**
2. Press <MENU/OK> and <UP/DOWN> to select **PBX ACCESS.**
3. Press<MENU/OK> to show CODE, then enter your access digit (1-0) and press <MENU/OK> to confirm it and activate the feature.

Note: Press <C/MUTE> to delete any access digit, and deactivate the feature.

7.5 Registration

IMPORTANT: When you purchase your phone system, all handsets and the headset are already registered to your base, so you do not need to register them.

Handset registration is only necessary when you buy extra handset or if a handset has become faulty.

You can register additional handsets to have up to five handsets per base unit, with each handset's number (1 to 5) shown on its display. (Note: each handset can only be registered to one base.)

7.5.1 To register a new handset to your base:

1. Press and hold <FIND> on the base station for more than five seconds, to put the base station into registration mode. It will stay in registration mode for about 1 minute, so the following handset sequence must be completed within this time.
2. Press <MENU/OK> and <UP/DOWN> to select **REGISTRATION.**
3. Press <MENU/OK> to display PIN?------.
4. Enter the 4-digit system PIN(default0000).
5. Press <MENU/OK> to confirm, and the display will show PLEASE WAIT.

If the handset registration is successful, you will hear a confirmation tone and the <antenna icon> will stop flashing.

The handset will automatically be allocated the next available handset number.

This handset number is shown in the handset display in standby mode. If the handset registration is unsuccessful, the <antenna icon> will still flash.

7.5.2 To register an additional wireless headset

IMPORTANT: The wireless headset is pre-registered when supplied and should not need to be registered. Headset registration is only necessary when you buy a new headset or if it has lost its registration, and the headset LED is purple.

Note: Before trying to register a headset to the base station, make sure the base station system PIN code is set to 0000, otherwise you will not be able to register the headset

1. Press and hold VOLUME UP / FLASH [+] together with VOLUME DOWN [-] to put the headset into registration mode. The LED on the wireless headset will toggle between red and blue.
2. Press and hold <FIND> on the base station for more than five seconds, to put the base station into registration mode.
3. Place the unregistered wireless headset on the base charging bay.
4. The headset LED will flash blue for about 3 seconds and a long beep tone is generated if the registration is successful.

Note: If the headset LED flashes slowly in purple, it means that the headset is registered but the base is not available.

7.6 Reset Your Phone

You can reset your phone to the default settings . After a reset, all your personal settings, call list entries, redial list entries, and answering machine messages will be deleted but your phonebook remains unchanged.

1. Press <MENU/OK> and <UP/DOWN> to select **DEFAULT.**
2. Press <MENU/OK> to display PIN?-----.
3. Enter the 4-digit system PIN(default 0000).
4. Press <MENU/OK> to display CONFIRM?
5. Press <MENU/OK> to confirm, and the phone will be reset to its default settings.

8 ANSWERING MACHINE

Your phone includes a telephone answering machine that records unanswered calls when it is on.The answering machine can store up to 59 messages within the maximum recording time of approximately 15 minutes. As well as recording incoming messages, you can record memos for other users of your phone.
If the answering machine memory is full, the Handset will display TAM FULL lt ernately with the handsets name or time, depending on the handset standby display mode set (see section 7.3.7), and you will have to delete some messages before any new ones can be recorded.

Some answering machine functions can be operated from the base, including playing messages and turning the answering machine on or off. See section "3.3 Base Station with Telephone Answering Machine (TAM) Control" for further details.
The answering machine can also be controlled and set up using the handset menu functions, as below.

8.1 Turn On/Off the Answering Machine

You can turn the answering machine on or off using the handset.

When the answering machine is set to ON, calls will be answered after the set answer delay and the caller can then leave you a message.
When the answering machine is set to OFF, calls will be answered after 14 rings and the answer only message will be played to your callers. They will not be able to leave you a message.

1. Press <MENU/OK> and <UP/DOWN> to select **ANS. MACHINE.**
2. Press <MENU/OK> and <UP/DOWN> to select **TAM ON/OFF.**
3. Press <MENU/OK> and <UP/DOWN> to select **ON** or **OFF.**
4. Press <MENU/OK> to confirm.

- If answering machine is set to ON, <TAM ON icon> displays on the handset LCD.
- If answering machine is set to OFF, <TAM ON icon> will not display on the handset LCD.

8.2 Listen to the Messages in the Answering Machine

When new messages are recorded on the answering machine, the <TAM icon> flashes on the handset display until all the new messages are played.

After a new message is played it will be saved as an old message automatically unless it is deleted.

Old messages will be played after all new messages are played completely.

1. Press <MENU/OK> and <UP/DOWN> to select **ANS. MACHINE.**
2. Press <MENU/OK> and <UP/DOWN> to select **MSG PLAYBACK.**
3. Press <MENU/OK> to start message playback through the loudspeaker and the screen displays the date and time information of the message received.

Note: A <STAR icon> is placed at the centre of the bottom of the handset display to indicate that it is a new message.
When a message has been played, the <STAR icon> will disappear and will not be shown when you listen to this message again.

Note: If there are no messages, the handset display will briefly show **"00-00 00-00"** then return to MSG PLAYBACK.

4. During playback, press <UP> or <DOWN> to increase or decrease the volume or press <SPEAKERPHONE> to go between earpiece and loudspeaker.
5. Press <MENU/OK> and <UP/DOWN> to selectthe following functions during message playback.

STOP: Stop the playback and return to the **ANS. MACHINE** menu.
FORWARD: Skip to play the next message.
PREVIOUS: Repeat playing the current message from the beginning.
DELETE: Delete the current message and the next message will be played.

Note: Alternatively, you can use the following shortcut keys to control different operations during message playback.

Press <Key 5> to stop message playback.
Press <Key 4> once to skip to repeat playing the current message from the beginning. Press twice to skip backward to play the previous message.
Press <Key 6> to skip to play next message.
Press <Key 2> to delete the current message playback.

8.3 Delete All Messages in the Answering Machine

1. Press <MENU/OK> and <UP/DOWN> to select **ANS. MACHINE.**
2. Press <MENU/OK> and <UP/DOWN> to select **DELETE ALL.**
3. Press <MENU/OK> to display CONFIRM?
4. Press <MENU/OK> to delete all old messages.

Note: If there are no more messages in the answering machine, "***EMPTY***" will display and return back to **ANS. MACHINE** menu.

8.4 Record Memo

You can record a memo message for another user. When you record a memo, the message counter will increase by one and the message can be played back in the same way as answering machine messages. Memo recording can still function even when the answering machine is turned off.

1. Press <MENU/OK> and <UP/DOWN> to select **ANS. MACHINE.**
2. Press <MENU/OK> and <UP/DOWN> to select **MEMO.**
3. Press <MENU/OK> to start memo recording and "***RECORDING***" is displayed.
4. Press <MENU/OK> to stop memo recording and save the memo.

OR

4. Press <CMUTE> to stop memo recording without saving and return back to **ANS. MACHINE** menu.

8.5 Answering Machine Settings

You can use the **TAM SETTINGS** menu through the handset to change the settings of your answering machine.

8.5.1 Set the Answer Mode

By default, the answer machine is set in **ANS & REC** mode which allows callers to leave a message. This mode can be changed to **ANSWER ONLY** which does not allow callers to leave a message. In that case, your callers will be prompted to call back later.

1. Press <MENU/OK> and <UP/DOWN> to select **ANS. MACHINE.**
2. Press <MENU/OK> and <UP/DOWN> to select **TAM SETTINGS.**
3. Press <MENU/OK> and <UP/DOWN> to select **ANSWER MODE.**
4. Press <MENU/OK> and <UP/DOWN> to select **ANS & REC** or **ANSWER ONLY.**
5. Press <MENU/OK> to confirm.

When your answering machine memory is full and it is in **ANS & RECORD**,the answer mode will change to **ANSWER ONLY** automatically. It will return to **ANS & RECORD** mode automatically after some messages have been deleted.

8.5.2 Record Your Own Outgoing Message (OGM)

You can record your own OGM for **ANS & REC** mode or **ANSWER ONLY** mode. When you record your own OGM, it will be used when the answering machine answers the call. If your personalised OGM is deleted, the pre-set OGM will be restored automatically.

1. Press <MENU/OK> and <UP/DOWN> to select **ANS. MACHINE.**
2. Press <MENU/OK> and <UP/DOWN> to select **TAM SETTINGS.**
3. Press <MENU/OK> and <UP/DOWN> to select **OGM SETTINGS.**
4. Press <MENU/OK> and <UP/DOWN> to select **ANS & REC** or **ANSWER ONLY.**
5. Press <MENU/OK> and <UP/DOWN> to select **RECORD MESS.**
6. Press <MENU/OK> to start recording your personalised OGM and ***"RECORDING"*** is displayed on the screen.
7. Press <MENU/OK> to stop and save your personalised OGM. Your newly saved OGM will playback automatically.
   Alternatively, press <BACK> to return to previous screen without saving the personalised OGM.

8.5.3 Playback and Delete the Outgoing Message (OGM)

You can playback your own personalised OGM or the pre-set OGM for **ANS & REC** mode or **ANSWER ONLY** mode and choose to delete your personalised OGM during playback and record a new one whenever you want.

Please note that pre-set OGM cannot be deleted.

8.5.3.1 Playback the OGM

1. Press <MENU/OK> and <UP/DOWN> to select **ANS. MACHINE.**
2. Press <MENU/OK> and <UP/DOWN> to select **TAM SETTINGS.**
3. Press <MENU/OK> and <UP/DOWN> to select **OGM SETTINGS.**
4. Press <MENU/OK> and <UP/DOWN> to select **ANS & REC** or **ANSWER ONLY.**
5. Press <MENU/OK> and <UP/DOWN> to select **PLAYBACK.**
6. Press <MENU/OK> to playback your current OGM and ***"PLAYING OGM"*** is displayed on the screen.
7. Press <MENU/OK> to stop the OGM playback and return to the previous menu.

Note: If a personalised OGM has not been recorded, the pre-set OGM will be played.

8.5.3.2 Delete the Personalised OGM

1. Repeat Steps 1 to 6 in Section 8.5.3.1
2. Press <C/MUTE> while the OGM is playing to delete your personalised OGM and return to the previous menu and the pre-set OGM is restored automatically.

Note: If the pre-set OGM is playing, you are not allowed to delete it, so pressing <C/MUTE> will just stop the playback and return to the previous menu.

8.5.4 Set the Answer Delay

You can set the number of rings before the answering machine answers and starts playing your OGM. You can set the answering machine to answer after two to eight rings or **TIME SAVER.** If Time Saver is set the answering machine will answer after 4 rings if there are no new messages, or after 2 rings if there is a new message, so if you call in and you don't get an answer after 2 or 3 rings, you can hang up and save on call charges.

1. Press <MENU/OK> and <UP/DOWN> to select **ANS. MACHINE.**
2. Press <MENU/OK> and <UP/DOWN> to select **TAM SETTINGS.**
3. Press <MENU/OK> and <UP/DOWN> to select **ANSWER DELAY (Available options: 2 RINGS, 4 RINGS, 6 RINGS, 8 RINGS or TIME SAVER).**
4. Press <MENU/OK> and <UP/DOWN> to select your desired answer delay.
5. Press <MENU/OK> to confirm.

8.5.5 Set the Recording Time of Incoming Message

You can set the maximum length of the recording time of the incoming messages.

1. Press <MENU/OK> and <UP/DOWN> to select **ANS. MACHINE.**
2. Press <MENU/OK> and <UP/DOWN> to select **TAM SETTINGS.**
3. Press <MENU/OK> and <UP/DOWN> to select **RECORD TIME (Available options: 60S, 120S, 180S, or UNLIMITED).**
4. Press <MENU/OK> and <UP/DOWN> to select your desired recording time.
5. Press <MENU/OK> to confirm.

8.5.6 Call Screening

When the answering machine is on and takes a call, you can listen to the caller leaving a message. You can then identify the caller and decide whether to take the call in person. The call can be screened at the base and with any handset.

8.5.6.1 Screening at the base

By default, answering machine calls are played automatically through the base speaker and the volume can be adjusted with the VOL + and VOL - keys on the base.

If you don't want the caller to be heard when leaving a message, the base screening can be turned off.

1. Press <MENU/OK> and <UP/DOWN> to select **ANS MACHINE.**
2. Press <MENU/OK> and <UP/DOWN> to select **TAM SETTINGS.**
3. Press <MENU/OK> and <UP/DOWN> to select **BS SCREENING.**
4. Press <MENU/OK> and <UP/DOWN> to select OFF or ON. (The current setting will be indicated by a *.)
5. Press <MENU/OK> to confirm the setting.

8.5.6.2 Screening with a handset

If the answering machine is set to ON, when there is an incoming message, the handset will display "**SCREENING?**"

1. Press <MENU/OK> to start call screening. Any Handset can listen to who is leaving the message and decide whether to pick up the call or not.
2. The handset will display "**SCREENING**".
3. You can adjust the earpiece volume by pressing <UP or DOWN>.

OR

3. Press <C/MUTE> to return to previous screen and you cannot hear the recording. At any time if you want to pick up the call, you can press <TALK> and the message recording will be stopped automatically. If the answering machine is in the process of recording, the message already stored will be saved.

8.5.7 Change the Compression Rate

Three different compression rates (**HIGH**, **MEDIUM** and **LOW**) are provided for you to select different quality levels of recording incoming message. The lower the compression rate, the higher the recording quality level attained, but the shorter the total recording time available. (LOW=7 minutes, MEDIUM=10 minutes, HIGH=15 minutes approx).

1. Press <MENU/OK> and <UP/DOWN> to select **ANS. MACHINE.**
2. Press <MENU/OK> and <UP/DOWN> to select **TAM SETTINGS.**
3. Press <MENU/OK> and <UP/DOWN> to select **COMPRESSION.**
4. Press <MENU/OK> and <UP/DOWN> to select your desired compression rate.
5. Press <MENU/OK> to confirm.

8.5.8 Activate Remote Access

Your phone lets you check your messages, or otherwise operate your answering machine, by calling the answering machine when you are away from home and then dialling a 4-digit remote access PIN from a tone-dialling phone.

The 4-digit remote access PIN code is used to prevent other people from unauthorised access of your answering machine.

Note: Remote Access must be turned on if you want to be able to use this feature, see 8.5.8.2.

8.5.8.1 Change the 4-Digit Remote Access PIN

1. Press <MENU/OK> and <UP/DOWN> to select **ANS. MACHINE.**
2. Press <MENU/OK> and <UP/DOWN> to select **TAM SETTINGS.**
3. Press <MENU/OK> and <UP/DOWN> to select **CHANGE PIN.**
4. Press <MENU/OK> and enter the Old PIN. (Default Remote Access PIN is 0000).
5. Press <MENU/OK> and enter the New PIN.
6. Press <MENU/OK> and enter the New PIN again.

Note: If the new PIN entered in Step 6 is not the same as the new system PIN entered in Step 5, you must enter the new system PIN at step 5 again.

7. Press <MENU/OK> to reconfirm.

8.5.8.2 Activate or Deactivate the Remote Access

1. Press <MENU/OK> and <UP/DOWN> to select **ANS. MACHINE.**
2. Press <MENU/OK> and <UP/DOWN> to select **TAM SETTINGS.**
3. Press <MENU/OK> and <UP/DOWN> to select **REMOTE ACC.**
4. Press <MENU/OK> and <UP/DOWN> to select **ON** or **OFF** to turn the remote access on or off respectively.
5. Press <MENU/OK> to confirm.

8.5.8.3 Access Your Answering Machine Remotely

You can ring your phone from another tone-dialling phone to switch the answering machine on or off, and/or listen to your messages remotely.

1. Place a call from a tone-dialling phone to your phone.
2. When the answering machine answers the call and starts playing the OGM, press the <*> key. The OGM will stop playing
3. Enter the 4-digit Remote Access PIN (default PIN is 0000). You will hear a single beep if the PIN is accepted, and you will need to press 5 to start playing any messages. If the PIN is not accepted you will hear a triple error beep, and you will need to enter the PIN again.

Note: The * must be entered while the OGM is still playing, and the 4-digit PIN should be follow without any delays.

Note: If the 4-digit Remote Access PIN is entered incorrectly three times consecutively, the line will be released automatically.

4. Press the following keys to carry out your desired function.

Freedom System

iDECT

Remote operation

1 **Using a tone-dialling phone, dial your home number**

2 **While your outgoing message is playing, press** ✱

3 **Key in your remote security code**

The default code is 0000. For details of how to set a new code, see the User Guide 8.5.8.1 on page 32.

Note: The <*> key must be entered while the OGM is still playing, and the 4-digit PIN should follow without any delays. If the 4-digit Remote Access PIN is entered incorrectly three times consecutively, the line will be released automatically.

4 **You can also use the codes on the other side of this card**

Note: If your answering machine is switched off, the phone will enter into the remote access mode after 14 rings.
You can then enter the 4-digit remote access PIN
(Default Remote Access PIN is 0000) to activate the remote access feature.

Keys	Functions	
	While message is not playing	**While message is playing**
2		Delete the current message playing
4		Repeat playing the current message from the beginning.Press twice to skip backward to play the previous message.
5	Play the message	Stop the current message playback
6		Skip to play the next message
7	Turn on the answering machine	
8		Stop the current message playback
9	Turn off the answering machine	

Note: If your answering machine is switched off, the phone will enter into the remote access mode after 14 rings.
You can then enter the <*> key and the 4-digit remote access PIN (Default Remote Access PIN is 0000) to activate the remote access feature.

Keys	Functions	
	While message is not playing	**While message is playing**
2		Delete the current message playing.
4		Repeat playing the current message from the beginning. Press twice to skip backward to play the previous message.
5	Play the message	Stop the current message playback
6		Skip to play the next message
7	Turn on the answering machine	
8		Stop the current message playback
9	Turn off the answering machine	

9 TROUBLESHOOTING

Problem	Causes	Solutions
No dialling tone when pressing <TALK > key	a. The connection cord of the base station is not plugged in. b. The adapter cord is not plugged in correctly in the base station. c. Another handset is using the base to make a call. d. Wrong telephone line cord	a. Check the connections. Unplug and plug back in the mains. Check that the telephone cord has been plugged into the base station and the phone socket. b. Check the base station plug and the 230V plug (remove and plug-in). c. Wait until the line is unoccupied. d. Use the original telephone line cord supplied
When connect to a PBX, no and/or wrong connection after dialling.	Dialling prefix is needed.	Insert the dialling prefix
"SEARCHING" is displayed.	a. Base station out of range. b. Base station not connected to mains.	Reduce the range. Connect base station to mains.
The call does not work.	Service not activated or wrong setting	Check your Subscription with network or change the dial mode.
No display.	Empty battery	Recharge battery
Answering Machine		
The unit does not record new messages.	The answering machine is turned off.	Turn on the answering machine.
The caller cannot leave a message.	a. The answering machine is turned off. b. Message memory is full. c. ANSWER ONLY mode is set.	a. Turn on the answering machine. b. Erase unnecessary messages. c. Change to ANS & REC mode.
I cannot operate the answering machine remotely.	a. You are entering the wrong remote access code b. You are pressing the dial keys too quickly. c. You are using a pulse telephone.	a. If you forget the remote access code, reset to the default settings. b. Press each key firmly. c. Try again using a touch tone phone.
While recording an outgoing message or listening to messages, the unit rings and recording stops.	A call is being received.	Answer the incoming call and try again to record your out going message later.

Please contact the technical support of the network provider for further information.

This telephone is not equipped with a grounding function, and therefore some of the functions may be limited when used in PBX systems.

Technical Support

If the fault persists...

Disconnect all other instruments connected to the same line as the phone system and try to make a call.

Disconnect the base unit from the telephone line and plug a different phone into the master telephone socket.

Try making a call. If this works, the line is OK.

If the call does not work,and you are using a **two-way socket adapter,** remove it and plug a telephone directly into the socket. If the call now works, the adapter may be faulty.

10 DECLARATION OF CONFORMITY

We the manufacturer / Importer : Binatone Telecom Plc,1 Apsley Way London, NW2 7HF.

Declare under our sole responsibility that the following product

Type of equipment:	Digital cordless telephone
Model Name:	Freedom Series
Country of Origin:	China
Brand:	Binatone

complies with the essential protection requirements of R&TTE Directive 1999/5/EC on the approximation of the laws of the Member States relating to ***Radio Spectrum Matters,*** the Council Directive 2004/108/EC on the approximation of the laws of the Member Statesrelating to ***electromagnetic compatibility (EMC)*** and the European Community Directive 2006/95/EC relating to ***Electrical Safety.***

Assessment of compliance of the product with the requirements relating to the essential requirements according to Article 3 R&TTE was based on Annex III of the Directive 1999/5/EC and the following standard:

Radio Spectrum:	ETSI EN 301406 : V 2.1.1 (2009-07)
EMC:	ETSI EN 301489-6: V1.3.1 (2008-08)
	ETSI EN 301489-1: V1.8.1 (2008-04)
Safety:	EN60950 -1 : 2006 + A11: 2009

Manufacturer / Importer
(signature of authorized person)

15 July 2011
Date

Signature

The conformity to the requirements is validated by the CE symbol.

NOTE: *In compliance with Directive 2002/96/EC, when you purchase a product that comes with the symbol shown on the right, you are required to dispose of electrical and electronic equipment by separate waste collection and you cannot dispose of the product as normal waste.*

This equipment and all its components, subsystems and consumable materials formed an integral part of this product and when you decide to dispose of them you have to takethem to a local recycling centre for appropriate waste disposal, in compliance with the current regulations. Details about the location of these centres can be obtained from your local authority.

Notes for battery disposal

Your product contains batteries covered by the European Directive 2006/66/EC, which cannot be disposed of with normal household waste.

Please be aware of the local rules on separate collection of batteries. The correct disposal of batteries helps protect the environment and prevent health hazards.

11 PRODUCT GUARANTEE

The phone system is guaranteed for 12 months from the date of purchase shown on your sales receipt. This guarantee does not cover any faults or defects caused by accidents, misuse, fair wear and tear, neglect, faults on the telephone line, lightning, tampering with the equipment, or any attempt at adjustment or repair other than through approved agents.

Please keep your sales (till) receipt this is your guarantee.

You should also keep the original packaging material.

In the unlikely event that you need to return your phone system to our Repair Centre while it is under guarantee, there may be a handling charge.

While the unit is under Guarantee

1. Disconnect the base unit from the telephone line and the mains electricity supply.
2. Pack up all parts of your Phone system , using the original packaging.
3. Return the unit to the shop where you bought it, making sure you take your sales receipt.

   Remember to include the mains adapter.

After the Guarantee has expired

If the unit is no longer under Guarantee, first follow steps 1 and 2 as for repair under Guarantee. Then...

3. Call Helpline on 0845 345 9677 (for UK only) and ask for a quotation of the repair charge and details of where to send your phone system for repair.
4. Make sure you include with your phone system.

- Your name and address
- A cheque or postal order for the value of the repair
- A brief description of the fault.

5. Return your phone system to the address given by the Service. Department.

* *This does not affect your statutory rights.*